

# Structured Electronics Design and SLiCAP

On what it is based

What do you do

Use SLiCAP

# Structured Electronics Design and SLiCAP

On what it is based

What do you do

Use SLiCAP

Define the (next) design problem

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

## What do you do

Define the (next) design problem

## Use SLiCAP

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

## What do you do

Define the (next) design problem

## Use SLiCAP

Create a python script for each design problem to solve

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

## Use SLiCAP

Create a python script for each design problem to solve

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

## Use SLiCAP

Create a python script for each design problem to solve

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

Circuit performance analysis is what we learned at school

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

Circuit performance analysis is what we learned at school

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

Perform one out of 16 predefined mixed symbolic/numeric analysis types

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

Circuit performance analysis is what we learned at school

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

Solve these expressions for assigned performance and/or cost budgets

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

Perform one out of 16 predefined mixed symbolic/numeric analysis types

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

Circuit performance analysis is what we learned at school

Determine ranges rather than valid values for design parameter of interest

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

Solve these expressions for assigned performance and/or cost budgets

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

Perform one out of 16 predefined mixed symbolic/numeric analysis types

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

Circuit performance analysis is what we learned at school

Determine ranges rather than valid values for design parameter of interest

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

Solve these expressions for assigned performance and/or cost budgets

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

Perform one out of 16 predefined mixed symbolic/numeric analysis types

Use a sympy or numpy solvers to obtain numeric values, ranges of values or relations between design parameters and store them in the database

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

Circuit performance analysis is what we learned at school

Determine ranges rather than valid values for design parameter of interest

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

Solve these expressions for assigned performance and/or cost budgets

Select values for design parameters

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

Perform one out of 16 predefined mixed symbolic/numeric analysis types

Use a sympy or numpy solvers to obtain numeric values, ranges of values or relations between design parameters and store them in the database

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

Circuit performance analysis is what we learned at school

Determine ranges rather than valid values for design parameter of interest

Only take design decisions if necessary

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

Solve these expressions for assigned performance and/or cost budgets

Select values for design parameters

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

Perform one out of 16 predefined mixed symbolic/numeric analysis types

Use a sympy or numpy solvers to obtain numeric values, ranges of values or relations between design parameters and store them in the database

# Structured Electronics Design and SLiCAP

## On what it is based

A structured design method helps you to define when what to do

A structured design method helps you with orthogonalization of your design

A structured design method helps you to create circuit concepts

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

A structured design method helps you to define circuit models

Albert Einstein: "Everything should be made as simple as possible, but not simpler"

G.P. Box: "All models are wrong, but some are useful"

Keep the number of symbolic parameters in expressions as small as possible

Circuit performance analysis is what we learned at school

Determine ranges rather than valid values for design parameter of interest

Only take design decisions if necessary

## What do you do

Define the (next) design problem

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and cost factors from parent-level budgets

Define solutions for the design problem (concepts and possible implementations)

Define design parameters of these implementations to be determined

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Import values of design parameters defined at an earlier stage

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

Solve these expressions for assigned performance and/or cost budgets

Select values for design parameters

## Use SLiCAP

Create a python script for each design problem to solve

Store budgets and target values in a design database

Put drawings and text in your design document

Define symbolic variables

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Import parameter values from the database and assign them to circuit parameters

Perform one out of 16 predefined mixed symbolic/numeric analysis types

Let the designer assign (input) final values and store them in the database

# Structured Electronics Design and SLiCAP

## On what it is based

## What do you do

## Use SLiCAP

A structured design method helps you to define when what to do

Define the (next) design problem

Create a python script for each design problem to solve

A structured design method helps you with orthogonalization of your design

Define relevant performance parameters and cost factors for the solution and derive child-level budgets for these performance parameters and costs factors from parent-level budgets

Store budgets and target values in a design database

A structured design method helps you to create circuit concepts

Define solutions for the design problem (concepts and possible implementations)

Put drawings and text in your design document

Relevant design parameters follow from the physical operation and its technological implementation in electronic devices

Define design parameters of these implementations to be determined

Define symbolic variables

A structured design method helps you to define circuit models  
Albert Einstein: "Everything should be made as simple as possible, but not simpler"  
G.P. Box: "All models are wrong, but some are useful"

Create network models of solutions (simple but complete enough) that relate relevant performance parameters and cost factors to these design parameters

Create a KiCAD schematic with SLiCAP symbols and generate a circuit object from it

Keep the number of symbolic parameters in expressions as small as possible

Import values of design parameters defined at an earlier stage

Import parameter values from the database and assign them to circuit parameters

Circuit performance analysis is what we learned at school

Yield expressions that relate performance parameters and/or cost factors to design parameters of interest

Perform one out of 16 predefined mixed symbolic/numeric analysis types

Determine ranges rather than valid values for design parameter of interest

Solve these expressions for assigned performance and/or cost budgets

Use a sympy or numpy solvers to obtain numeric values, ranges of values or relations between design parameters and store them in the database

Only take design decisions if necessary

Select values for design parameters

Let the designer assign (input) final values and store them in the database